



Data Preprocessing

Workshop on RNA-Seq Roy Francis and Nima Rafati NBIS, SciLifeLab

Raw data



Raw count table

```
##
                       DSSd00 1 DSSd00 2 DSSd00 3 DSSd07 1 DSSd07 2 DSSd07 3
## FNSMUSG00000102693
                              0
                                       0
                                                                    0
                                                                             0
## ENSMUSG00000064842
                                                 0
                                                                             0
## FNSMUSG00000051951
                                                          0
## ENSMUSG00000102851
                                                          0
                                                                             0
## ENSMUSG00000103377
                                                                             0
## ENSMUSG00000104017
                                                                             0
```

Metadata

```
SampleName
                        SampleID No Model Day Group Replicate
##
## DSSd00 1 DSSd00 1 KI PC1606 01 1 DSS 0 day00
## DSSd00 2 DSSd00 2 KI PC1606 02 2 DSS
                                           0 day00
## DSSd00 3
            DSSd00 3 KI PC1606 03 3 DSS
                                           0 day00
## DSSd07 1
            DSSd07 1 KI PC1606 13 13
                                     DSS
                                          7 dav07
## DSSd07 2
            DSSd07 2 KI PC1606 14 14
                                     DSS
                                           7 day07
            DSSd07 3 KI_PC1606_15 15
## DSSd07 3
                                      DSS
                                           7 day07
```

Filtering




• Remove genes and samples with low counts

```
cf1 <- cr[rowSums(cr>0) >= 3, ] # Keep rows/genes that have at least one read in +3 samples cf2 <- cr[rowSums(cr>3) >= 3, ] # Keep rows/genes that have at least three reads in +3 samp cf3 <- cr[rowSums(edgeR::cpm(cr)>5) >= 3, ] # need at least three samples to have cpm > 5.
```

count/read per million (cpm/rpm): a normalized value for sequencing depth.

Inspect distribution





Inspect the number of rows (genes) available after filtering

Raw: 55487, Method 1: 16099, Method 2: 11783, Method 3: 12496



- Removing technical biases in sequencing data (e.g. sequencing depth and gene length)
- Make counts comparable across features (genes).
- Make counts comparable across samples









• Controlling for gene length: It can be useful for gene to gene comparisons.

Sample A Reads





```
## counts gene_length norm_counts
## x 50 10 5
## y 25 5
```

• Bring counts to a human-friendly scale



Normalisation by library size

- Assumes total expression is the same under different experimental conditions
- Methods include TC, RPKM, FPKM, TPM
- RPKM, FPKM and TPM control for sequencing depth and gene length
- Total number of RPKM/FPKM normalized counts for each sample will be different, therefore, you cannot compare the normalized counts for each gene equally between samples.
- TPM is proportional to RPKM and enables better comparison between samples because total per sample sums to equal value

```
## A B len A_rpm B_rpm A_rpkm B_rpkm A_rpk B_rpk A_tpm B_tpm

## x 20 6 2000 408163 222222 204081.5 111111.0 10.00 3.0 493827 153846

## y 25 6 4000 510204 222222 127551.0 55555.5 6.25 1.5 308642 76923

## z 4 15 1000 81633 555556 81633.0 555556.0 4.00 15.0 197531 769231

## sum 49 27 7000 1000000 1000000 413265.5 722222.5 20.25 19.5 1000000 1000000
```

rpm = cpm.

🔳 Ø Evans, Ciaran, Johanna Hardin, and Daniel M. Stoebel. "Selecting between-sample RNA-Seq normalization methods from the perspective of their

ssumptions." Briefings in bioinformatics (2017)



Normalisation by distribution

- Assumes technical effects are same for DE and non-DE genes
- Assumes number of over and under-expressed genes are roughly same across conditions
- Corrects for compositional bias
- Methods include Q, UQ, M, RLE, TMM, MRN
- edgeR::calcNormFactors() implements TMM, TMMwsp, RLE & UQ
- DESeq2::estimateSizeFactors() implements relative log expression (RLE)
- Does not correct for gene length
- geTMM is gene length corrected TMM

```
## A B len ref A_ratio B_ratio A_mrn B_mrn

## x 20 6 2000 10.95 1.83 0.55 10.928962 10.90909

## y 25 6 4000 12.25 2.04 0.49 13.661202 10.90909

## z 4 15 1000 7.75 0.52 1.94 2.185792 27.27273
```

🔳 Ø Evans, Ciaran, Johanna Hardin, and Daniel M. Stoebel. "Selecting between-sample RNA-Seq normalization methods from the perspective of their

assumptions." Briefings in bioinformatics (2017)



Normalisation by testing

- A more robust version of normalisation by distribution
- A set of non-DE genes are detected through hypothesis testing
- Tolerates a larger difference in number of over and under expressed genes between conditions
- Methods include PoissonSeq, DEGES

Normalisation using Controls

- Assumes controls are not affected by experimental condition and technical effects are similar to all other genes
- Useful in conditions with global shift in expression
- Controls could be house-keeping genes or spike-ins
- Methods include RUV, CLS

Stabilizing variance

- Variance is stabilised across the range of mean values
- Methods include VST, RLOG, VOOM
- For use in exploratory analyses. Not for DE.
- vst() and rlog() functions from DESeq2
- voom() function from *Limma* converts data to normal distribution



Recommendations

- Most tools use a mix of many different normalisations
- For DGE using DGE R packages (DESeq2, edgeR, Limma etc), use raw counts
- For visualisation (PCA, clustering, heatmaps etc), use VST or RLOG
- For own analysis with gene length correction, use TPM (maybe geTMM?)
- Custom solutions: spike-ins/house-keeping genes

🔳 🥝 Dillies, Marie-Agnes, et al. "A comprehensive evaluation of normalization methods for Illumina high-throughput RNA sequencing data analysis." Briefings in

oioinformatics 14.6 (2013): 671-683

Thank you. Questions?



